## Quick-Cleaning Convenience





## STANDARD Central Vacuum INLET VALVE

- One valve typically covers 600 to 700 square feet
- Insert hose into inlet valve to begin vacuuming
- Automatic on/off
- 30-35 foot hose is typically stored on a wall-mounted wire hose rack in closet, pantry, utility room, basement or garage
- Hose is carried from stored area to each inlet valve
- Lightweight hose weighs less than traditional vacuum cleaners
- Smaller inlet valve dimensions – similar to electric recepticle size
- Optional hose sock available for hoses

## HIDE-A-HOSE Retractable Hose System

- One valve stores up to a 50-foot retractable hose inside the wall – safely enclosed within the system's vacuum tubing when not in use
- One 50-foot hose can cover 1,800 to 2,200 square feet so less valves are needed per home for whole-house cleaning
- Only pull out the length of hose needed for a specific cleaning task, then when finished the power unit suction pulls the hose back into the wall and out of sight
- No storing or carrying a hose from valve to valve, simply attach the handle (with selected tool) or use hose end by itself
- · Instantly accessible with automatic on/off
- Hose has pre-installed hose sock





IH-124